FWHM

FWHM stands for **F**ull **W**idth at **H**alf-**M**aximum: a measure for the broadness of a peak, for example, of the IRF in an TCSPC measurement or the focal width(s) in a FLIM measurement.

see also FWHM

Copyright of this document belongs to PicoQuant GmbH. No parts of it may be reproduced, translated or transferred to third parties without written permission of PicoQuant GmbH. All information given here is reliable to our best knowledge. However, no responsibility is assumed for possible inaccuraciesor omissions. Specifi cations and external appearances are subject to change without notice.

PicoQuant GmbH
Rudower Chaussee 29 (IGZ)
12489 Berlin
Germany

P +49-(0)30-1208820-89
F +49-(0)30-1208820-90
info@picoquant.com
www.picoquant.com