How to exchange the main dichroic of the MicroTime 200

This video serves as additional support for the “Exchange of the main dichroic of the MicroTime 200.” section of the MicroTime 200 manual. It is only valid for systems equipped with a 3mm dichroic.

If you are unsure about any of the steps please contact** http://www.picoquant.com/support**.

Copyright of this document belongs to PicoQuant GmbH. No parts of it may be reproduced, translated or transferred to third parties without written permission of PicoQuant GmbH. All information given here is reliable to our best knowledge. However, no responsibility is assumed for possible inaccuraciesor omissions. Specifi cations and external appearances are subject to change without notice.

PicoQuant GmbH
Rudower Chaussee 29 (IGZ)
12489 Berlin
Germany

P +49-(0)30-1208820-89
F +49-(0)30-1208820-90
info@picoquant.com
www.picoquant.com