Chi square

The (normalized) χ^2 (read: chi square) is the optimization parameter for least squares fitting (for a definition see there). For a perfect fit it should be near 1. As a measure of the goodness-of-fit it is insufficient. Other methods have to be used in addition, like examining the weighted residuals trace and the autocorrelation function of the weighted residuals trace.

Copyright of this document belongs to PicoQuant GmbH. No parts of it may be reproduced, translated or transferred to third parties without written permission of PicoQuant GmbH. All information given here is reliable to our best knowledge. However, no responsibility is assumed for possible inaccuraciesor omissions. Specifi cations and external appearances are subject to change without notice.

PicoQuant GmbH
Rudower Chaussee 29 (IGZ)
12489 Berlin
Germany

P +49-(0)30-1208820-89
F +49-(0)30-1208820-90
info@picoquant.com
www.picoquant.com